


NXTGEN LEVER HOIST PARTS BREAKDOWN



No	Description	Qty	025 250 kg	050 500 kg	075 750 kg	150 1500 kg	300 3000 kg	No	Description	Qty	025 250 kg	050 500 kg	075 750 kg	150 1500kg	300 3000 kg
1	Top Hook Assembly (Incl. #2)	1	025-1	050-1	075-1	150-1	300-1	30	Brake Cover	1	025-30	050-30	075-30	150-30	~
2	Safety Latch Kit	2	025-2	050-2	075-2	150-2	300-2	31	Socket Head Screw & Spring Washer	3	025-31	050-31	075-31	150-31	~
3	Top Hook Shaft	1	025-3	050-3	075-3	150-3	~	33	Snap Ring for Brake Seat	1	025-33				
4	Bottom Hook Assembly (Incl. #2)	1	025-4	050-4	075-4	150-4	~	34	Change Over Gear	1	025-34	050-34	075-34	150-34	~
5	Chain Pin & Locking Nut	1	025-5	050-5	075-5	150-5	~	35	Lever Handle Assembly	1	025-35	050-35	075-35	150-35	~
7	Gear Case	1	025-7	050-7	075-7	150-7	~		Lever Handle	1	025-39	050-39	075-39	150-39	~
8	Reinforced Plate	1	025-8	050-8	075-8	150-8	~		Selector Lever	1	025-43	~	~	150-43	~
9	Load Gear	2	025-9	050-9	075-9	150-9	~		Change Over Pawl	1	025-44	050-44	~	150-44	~
10	Driving Pinion	1	025-10	050-10	075-10	150-10	~		Snap Ring for Change Over Pawl	1	025-45	~	~	~	~
11	Right Side Plate	1	025-11	050-11	075-11	150-11	~		Roller	1	025-46	~	~	~	~
12	Chain Stripper	1	025-12	050-12	075-12	150-12	~		Change Over Spring	1	025-47	~	~	~	~
13	Stay Bolt	2	025-13	050-13	075-13	150-13	~	36	Snap Ring	1	025-36	050-36	075-36	150-36	~
14	Pin	1		050-14	075-14	150-14	~	37	Hand Wheel	1	025-37	050-37	075-37	150-37	~
16	Load Gear	1	025-16	050-16	075-16	150-16	~	38	Snap Ring for Hand Wheel	1	025-38	~	~	~	~
17	Load Sheave	1	025-17	050-17	075-17	150-17	~	40	Handle Sleeve	1	025-40	050-40	075-40	150-40	~
18	Chain Guide	2	025-18	050-18	075-18	150-18	~	41	Bolt & Nut	1	025-41	~	~	~	~
19	Left Side Plate Assembly	1	025-19	050-19	075-19	150-19	~	48	Load Chain	1	025-48	050-48	075-48	150-48	~
20	Pawl Spring	2	025-20	~	~	150-20	~	49	End Ring	1	025-49	050-49	075-49	150-49	~
21	Pawl	2	025-21	~	~	~	~	50	Bottom Hook Holder	2					300-50
22	Snap Ring for Pawl	2	025-22	~	~	~	~	51	Idle Shaft	1					300-51
23	Brake Seat	1	025-23	050-23	075-23	150-23	~	52	quill roller	22					300-52
24	Ratchet Disc	1	025-24	050-24	075-24	150-24	~	53	Idle Sheave	1					300-53
25	Friction Disc	2	025-25	050-25	075-25	150-25	~	54	Screw & Nut	2					300-54
26	Spring	1	025-26	050-26	075-26	150-26	~	55	Screw & Nut	1					300-55
27	Brake Plate	1	025-27	050-27	075-27	150-27	~								
28	Bushing	1	025-28	050-28	075-28	150-28	~								
29	Stop Knob	1	025-29	050-29	~	150-29	~								

2018.7.30